

PU Cleaner / Dr. Schutz Cleaner



1 PRODUCT DESCRIPTION

Concentrated Cleaner for use on new floors immediately after installation and for the routine cleaning of floors factory-cured with a polyurethane finish as well as vinyl, linoleum or rubber floor coverings treated with PU Sealer.

- Excellent dirt-binding properties, even in the case of fatty deposits.
- Causes no damage to the floor surface, does not cause greying (development of grey filming).
- Does not leave a residue.
- Complies with the requirements of DIN 18032 for floors in sports areas, gyms, etc.

2 AREAS OF APPLICATION

Floors factory-cured with a polyurethane finish as well as vinyl, linoleum or rubber floor coverings treated with PU Sealer.

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

3 APPLICATION

Cleaning after installation:

Remove coarse dirt using a brush or vacuum cleaner. In case of stubborn dirt, dilute PU Cleaner in a ratio of 1:10 (1 litre to 10 litres of water), reducing the concentration accordingly for slight soiling. Distribute the cleaning solution over the floor and, after allowing to stand for a short time, treat the floor surface using a Monodisc appliance and red pad or scrubbing brush. Take up the dirt using a Dr. Schutz Spray extractor fitted with a hard floor adapter or absorbent wide-headed wiper mop and wipe over with clear water to neutralise.

Daily Cleaning:

Dilute PU Cleaner in a ratio of 1:200 (50 ml to 10 litres of water) and wipe over the floor using this solution. The concentration can be reduced to 1:400 (25 ml to 10 litres of water) when using a fully automatic cleaning appliance.

Note: Sensitive surfaces (such as wood, metal, furnishings) should not be sprayed with the cleaning solution.

4 CONSUMPTION

Cleaning after installation: ca. 2 litres per 100 m²

Daily Cleaning : ca. 0,1 litres per 100 m²

5 STORAGE

Store in cool, dry conditions in well sealed receptacles. Store under lock and key and out of the reach of children.

PU Cleaner / Dr. Schutz Cleaner



6 TECHNICAL DATA

Ingredients: contains under 5% anionic tensides, under 5% non ionic tensides. Contains perfumes (LIMONENE), solvents.

pH value: 9,5 (concentrate)

ADR/RID: no dangerous good according ADR

CLP: GHS07. Danger. H319 Causes serious eye irritation.

P101 If medical advice is needed, have product container or label at hand P102 Keep out of reach of children. P280 Wear protective gloves/protective clothing/eye protection/face protection.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes Remove contact lenses, if present and easy to do. Continue rinsing. P337+P313 If eye irritation persists Get medical advice/attention_P501 Dispose of contents/container in accordance with local/regional/national/international regulations.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied canisters can be disposed of in domestic waste, or taken to a recycling centre.

7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

8 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below.

PU Cleaner / Dr. Schutz Cleaner



Dr. Schutz – We Care About Floors

Headquarter
Dr. Schutz GmbH
Holbeinstraße 17
D-53175 Bonn
Tel.: +49 (0)228 / 95 35 2-40
Fax: +49 (0)228 / 95 35 2-46
E-Mail: export@dr-schutz.com
www.dr-schutz.com

UK
Dr. Schutz U.K Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP

Contact: Richard Nelson
Tel.: +44 (0)1296 437827
Fax: +44 (0)1296 334219
E-Mail: richard@dr-schutz.com

Ireland
Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork

Contact: Paul O'Reardon
Mobile: 0877678388
E-Mail: drschutzireland@gmail.com

North America
Schutz NA
4701 Bath St 46
Philadelphia PA 19137
USA

Contact: Sam Jamison
Tel.: +1 (877) 272-4889
Mobile: +1 (215) 510-7874
E-Mail: sam@schutzNA.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.